





STEP 1

STEP 2

STEP 3

BAND IS REMOVEABLE.
PULL OFF THE TOP BAND
TO GET TO CHARGING PORT

PLUG INTO USB PORT (NOTE: MAKE SURE YOUR WATCH IS RIGHT SIDE UP, OTHERWISE IT WILL NOT CHARGE)